


DTC	C1241/41	LOW BATTERY POSITIVE VOLTAGE
------------	-----------------	-------------------------------------

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1241/41	<ul style="list-style-type: none"> • With vehicle speed at 3 km/h (2 mph) or more, IG1 terminal voltage is 9.5 V or less for 10 sec. or more. 	<ul style="list-style-type: none"> • Battery • Charging system • Power source circuit


WIRING DIAGRAM



C I37521

INSPECTION PROCEDURE

1 INSPECT FUSE(ECU-IG FUSE)



- (a) Remove ECU-IG fuse from the instrument panel J/B.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
ECU - IG fuse	1 Ω or less

NG INSPECT FOR SHORT CIRCUIT IN ALL HARNESS AND COMPONENTS CONNECTED TO ECU-IG FUSE

OK

2 INSPECT BATTERY

- (a) Check battery positive voltage.

Standard:

Tester Connection	Specified Condition
Battery terminal (⊕ - ⊖)	11 to 14 V

NG CHECK AND REPLACE CHARGING SYSTEM

OK


3 INSPECT SKID CONTROL ECU TERMINAL VOLTAGE(IG1 TERMINAL)

WHEN USING HAND-HELD TESTER:

- (a) Connect the hand-held tester to the DLC3.
- (b) Start the engine.
- (c) Select the DATA LIST mode on the hand-held tester.
- (d) Check the voltage condition output from the ECU displayed on the hand-held tester.

Item	Measurement Item / Range (Display)	Normal Condition	Diagnostic Note
IG VOLTAGE	ECU power supply voltage/NORMAL or TOOL LOW	NORMAL: 9.5 V or over TOO LOW: Below 9.5 V	-

Standard:
"NORMAL" is displayed.



WHEN NOT USING HAND-HELD TESTER:

- (a) Disconnect the skid control ECU connector .
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
IG1 (S3-46) – GND (S3-1, 32)	10 to 14 V

NG Go to step 4


OK

REPLACE BRAKE ACTUATOR ASSY (See page 32-39)

NOTICE:

When replacing the brake actuator assy, perform the zero point calibration (See page 05-279).

4 INSPECT SKID CONTROL ECU CONNECTOR(GND TERMINAL CONTINUITY)



- (a) Disconnect the skid control ECU connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
GND (S3-1, 32) – Body ground	1 Ω or less

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPAIR HARNESS AND CONNECTOR