

# INSIDE VEHICLE

9900W-13

## GENERAL MAINTENANCE

Performing these maintenance checks on the vehicle is the owner's responsibility. The owner may perform the maintenance or take the vehicle to a service center.

Check the parts of the vehicle described below on a daily basis. In most cases, special tools are not required. It is recommended that the owner perform these checks.

The procedures for general maintenance are as follows.

### 1. GENERAL NOTES

- Maintenance requirements vary depending on the country.
- Check the maintenance schedule in the owner's manual supplement.
- Following the maintenance schedule is mandatory.
- Determine the appropriate time to service the vehicle using either miles driven or time (month) elapsed, whichever reaches the specification first.
- Maintain similar intervals between periodic maintenance unless noted.
- Failing to check each vehicle part could lead to poor engine performance and increase exhaust emissions.

### 2. LIGHTS

- (a) Check if that the headlights, stop lights, taillights, turn signal lights, and other lights illuminate or blink. Also, check if they have enough brightness.
- (b) Check if the headlights are aimed properly.

### 3. WARNING LIGHTS AND BUZZERS

- (a) Check that all the warning lights and buzzers are working.

### 4. HORN

- (a) Check that the horn is working.

### 5. WINDSHIELD GLASS

- (a) Check for scratches, pits or abrasions.

### 6. WINDSHIELD WIPER AND WASHER

- (a) Check if the wind washers are aimed properly. Also, check if the washer fluid hits the center of the operating range of each wiper on the windshield.
- (b) Check if the wipers streak or not.

### 7. WINDSHIELD DEFROSTER

- (a) When the heater or air conditioner is on the defroster setting, check if air comes out of the defroster outlet.

### 8. REAR VIEW MIRROR

- (a) Check that the rear view mirror is securely mounted.

### 9. SUN VISORS

- (a) Check that the sun visors move freely and are securely mounted.

### 10. STEERING WHEEL

- (a) Check that the steering wheel has the proper freeplay. Also check for steering difficulty, freeplay in the steering wheel and unusual noises.

### 11. SEATS

- (a) Check if the seat adjusters, seatback recliner and other front seat controls operate smoothly.
- (b) Check that all the latches lock securely in all positions.
- (c) Check that the locks hold securely in all latched positions.
- (d) Check that the head restraints move up and down smoothly and that the locks hold securely in all latched positions.
- (e) When the rear seatbacks are folded down, check if the latches lock securely.

**12. SEAT BELTS**

- (a) Check that the seat belt system such as the buckles, retractors and anchors operate properly and smoothly.
- (b) Check that the belt webbing is not cut, frayed, worn or damaged.

**13. ACCELERATOR PEDAL**

- (a) Check the pedal for smooth operation, uneven pedal effort and catching.

**14. CLUTCH PEDAL (See page 42-2)**

- (a) Check the pedal for smooth operation.
- (b) Check that the pedal has the proper freeplay.

**15. BRAKE PEDAL (See page 33-2)**

- (a) Check the pedal for smooth operation.
- (b) Check that the pedal has the proper reserve distance and freeplay.
- (c) Start the engine and check the brake booster function.

**16. BRAKES**

- (a) In a safe place, check that the vehicle remains straight when applying the brakes.

**17. PARKING BRAKE (See page 33-2)**

- (a) Check that the lever has the proper range of motion.
- (b) On a low incline, check if the parking brake alone can stabilize the vehicle.

**18. AUTOMATIC TRANSAXLE "PARK" MECHANISM**

- (a) Check the lock release button of the selector lever for proper and smooth operation.
- (b) On a low incline, check if the parking brake alone can stabilize the vehicle.