

















PREPARATION

SST

	09023-00100 Union Nut Wrench 10 mm	COIL SPRING REAR LH REAR AXLE BEAM ASSY
	09309-37010 Transmission Bearing Replacer	REAR AXLE BEAM ASSY
	09710-14013 Rear Suspension Bushing Tool Set	REAR AXLE BEAM ASSY
	(09710-00021) Pipe	REAR AXLE BEAM ASSY
	09950-40011 Puller B Set	REAR AXLE BEAM ASSY
	(09951-04010) Hanger 150	REAR AXLE BEAM ASSY
	(09952-04010) Slide Arm	REAR AXLE BEAM ASSY
	(09953-04010) Center Bolt 100	REAR AXLE BEAM ASSY
	(09953-04030) Center Bolt 200	REAR AXLE BEAM ASSY
	(09954-04020) Arm 100	REAR AXLE BEAM ASSY
	(09955-04031) Claw No.3	REAR AXLE BEAM ASSY
	(09955-04051) Claw No.5	REAR AXLE BEAM ASSY
	(09957-04010) Attachment	REAR AXLE BEAM ASSY

PREPARATION - REAR SUSPENSION

	(09958-04011) Holder	REAR AXLE BEAM ASSY
	09950-60010 Replacer Set	REAR AXLE BEAM ASSY
	(09951-00560) Replacer 56	REAR AXLE BEAM ASSY

Equipment

Torque wrench	
Dial indicator with magnetic base	
Wheel balancer	
Tire pressure gauge	
Alignment tester	
Toe-in gauge	
Camber-caster-kingpin gauge	
Drill (Safety equipment: protective goggles, etc.)	Shock absorber disposal