

TORQUE SPECIFICATION

Part Tightened		N·m	kgf·cm	ft·lbf
Park/neutral position switch Assy	Bolt:	5.4	55	48 in.·lbf
	Nut:	6.9	70	61 in.·lbf
Transmission control cable Assy x Control shaft lever		12	122	9
Automatic transaxle housing x Engine block		30	301	22
Torque converter clutch Assy x Drive plate		27	280	20
Oil cooler tube clamp x Automatic transaxle		5.5	56	49 in.·lbf
Oil cooler inlet tube sub-assy No.1 x Automatic transaxle		34	347	25
Oil cooler outlet tube sub-assy No.1 x Automatic transaxle		34	347	25
Transmission control cable bracket x Automatic transaxle		12	122	9
Transmission revolution sensor x Automatic transaxle		5.4	55	48 in.·lbf
Transmission oil filler tube sub-assy x Automatic transaxle		5.5	56	49 in.·lbf
Starter Assy x Automatic transaxle		37	380	27
Starter Assy x Starter wire		9.8	100	87 in.·lbf
Engine mounting bracket LH x Automatic transaxle		64	653	47
Engine mounting bracket RR x Automatic transaxle		49	500	36
Engine mounting bracket LH x Ground cable		26	260	19
Engine mounting bracket LH x Engine mounting insulator LH		49	500	36
Engine mounting bracket RR x Engine mounting insulator RR		64	653	47
Drain plug x Automatic transaxle oil pan		49	500	36
Automatic transaxle case x Transmission wire		5.4	55	48 in.·lbf
Automatic transaxle oil pan x Automatic transaxle case		7.8	80	69 in.·lbf
Oil strainer sub-assy x Transmission valve body Assy		11	110	8
Transmission valve body Assy x Automatic transaxle		11	110	8
Transmission valve body Assy x Manual detent spring sub-assy		11	110	8
Transmission valve body Assy x Shift solenoid valves		11	110	8
Transmission control cable Assy x Body		5.0	51	44 in.·lbf
Engine hanger x Engine		40	408	30
Control shaft lever x Park/neutral position switch Assy		13	130	9
Engine mounting bracket RR x Heat insulator		18	180	13
Engine block x Heat insulator		18	180	13
Air cleaner bracket x Automatic transaxle		19	195	14
Wire harness clamp bracket x Automatic transaxle		5.0	51	44 in.·lbf
Transmission control cable support x Automatic transaxle		12	122	9
Floor shift Assy x Body		12	122	9
Floor shift Assy x Transmission control cable Assy		12	122	9
Air cleaner Assy x Air cleaner bracket		7.8	80	69 in.·lbf
Air cleaner inlet No.2 x Body		7.5	76	66 in.·lbf
Shift lever knob x Shift lever sub-assy		2.2	22	19 in.·lbf
Front floor heat insulator No.1 x Body		5.5	56	49 in.·lbf