

HOW TO PROCEED WITH TROUBLESHOOTING

NOTICE:

When DTCs other than U0121/94, U0123/62, U0124/95, U0126/63 are output, inspect and repair the trouble areas indicated by the DTCs.

1	CHECK DLC3 SUB BUS LINE FOR DISCONNECTION (See page 05-702)
---	--



2	CHECK DTC COMBINATION (See page 05-701)
---	--



3	CIRCUIT INSPECTION
---	--------------------



4	IDENTIFICATION OF PROBLEM
---	---------------------------



5	REPAIR OR REPLACE
---	-------------------



6	CONFIRMATION TEST
---	-------------------



END
