

PROBLEM SYMPTOMS TABLE

The table below gives examples of the typical malfunction symptoms in the combination meter, and any problems can be solved by following the flowchart in each troubleshooting section.

Proceed to each troubleshooting page, and inspect and check the circuits and the parts following the flowchart.

Chart No.	Symptom	See page
1	Malfunction in speedometer	05-601
2	Malfunction in tachometer	05-603
3	Malfunction in fuel receiver gauge	05-606
4	Operating light control rheostat does not change light brightness	05-608
5	Entire combination meter does not operate	05-619
6	Warning buzzer does not sound	05-622
7	Seat belt warning lamp for driver's seat does not operate	05-629
8	Seat belt warning lamp for front passenger's seat does not flash	05-633