

**PROBLEM SYMPTOMS TABLE**

Symptom	Suspected Area	See Page
All doors cannot be locked/unlocked simultaneously	<ol style="list-style-type: none"> <li>1. D/L fuse</li> <li>2. GAUGE fuse</li> <li>3. Power window regulator master switch assy</li> <li>4. Front door lock actuator assy LH</li> <li>5. Door control switch assy</li> <li>6. Front door lock actuator assy RH</li> <li>7. Door control relay assy</li> <li>8. Wire harness</li> </ol>	<a href="#">05-645</a>
Key lock-in prevention function does not work properly (manual operation and key-linked lock are activated)	<ol style="list-style-type: none"> <li>1. Unlock warning switch assy</li> <li>2. Front door courtesy lamp switch assy (driver side)</li> <li>3. Door control relay assy</li> <li>4. Wire harness</li> </ol>	<a href="#">05-661</a>
Only back door cannot be opened (unlocked)	<ol style="list-style-type: none"> <li>1. Back door lock assy</li> <li>2. Back door opener switch assy</li> <li>3. Door control relay assy</li> <li>4. Wire harness</li> </ol>	<a href="#">05-664</a>