

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Only wireless control function does not operate (Prepare new or normal transmitter of the same type vehicle)	<ol style="list-style-type: none"> 1. Transmitter battery 2. Door transmitter sub-assy module set door control 3. Door control receiver 4. Unlock warning switch assy 5. Wire harness 6. Door control relay assy 	05-679
No answer-back (Hazard warning lamp)	<ol style="list-style-type: none"> 1. Lighting system 2. Wire harness 3. Instrument panel J/B assy 4. Door control relay assy 	05-687