

PROBLEM SYMPTOMS TABLE

Use the table below, with suspected areas listed in numerical order, to determine the cause of the problem. Inspect and replace or repair parts as necessary according to the steps on the following pages.

Symptom	Suspect Area	See page
Hard steering	1. Tires (Improperly inflated)	28-1
	2. Power steering fluid level (Low)	51-3
	3. Drive belt (Loose)	14-5
	4. Front wheel alignment (Incorrect)	26-7
	5. Steering system joints (Worn)	-
	6. Suspension arm sub assy lower No.1 (Worn)	26-15 26-20
	7. Steering column (Binding) Bound	-
	8. Power steering vane pump	51-8
	9. Power steering gear	51-20
Poor return	1. Tires (Improperly inflated)	28-1
	2. Front wheel alignment (Incorrect)	26-7
	3. Steering column (Binding) Bound	-
	4. Power steering gear	51-20
Excessive play	1. Steering system joints (Worn)	-
	2. Suspension arm sub assy lower No.1 (Worn)	26-15 26-20
	3. Front wheel bearing (Worn)	30-19
	4. Power steering gear	51-20
Abnormal noise	1. Power steering fluid level (Low)	51-3
	2. Steering system joints (Worn)	-
	3. Power steering vane pump	51-8
	4. Power steering gear	51-20