


DTC CHECK/CLEAR



1. DTC CHECK (USING SST CHECK WIRE)

(a) Checking DTCs using a SST check wire.


SST 09843-18040

- (1) Using SST, connect terminals Tc and CG of DLC3.
- (2) Turn the ignition switch to the ON position.
- (3) Read the DTC from the ABS warning light and VSC warning light on the combination meter.

HINT:


- If no code appears, inspect the diagnostic circuit, ABS warning light circuit or VSC warning light circuit.

Trouble Area	See page
Tc terminal circuit	05-356
ABS warning light circuit	05-334
VSC warning light circuit	05-339



- As an example, the blinking patterns for normal system code and codes 11 and 21 are shown on the left.
- (4) Codes are explained in the code table on page [05-281](#).
- (5) After completing the check, disconnect terminals Tc and CG of DLC3, and turn off the display.

If 2 or more are DTCs are detected at the same time, the DTCs will be displayed in ascending order.



(b) Clearing the DTCs using the SST check wire.

SST 09843-18040

- (1) Using SST, connect terminals Tc and CG of DLC3.
- (2) Turn the ignition switch to the ON position.
- (3) Clear the DTCs stored in ECU by depressing the brake pedal 8 times or more within 5 seconds.
- (4) Check that the ABS warning light and VSC warning light indicates the normal blinking patterns.
- (5) Remove the SST from the terminals of DLC3.

HINT:

Clearing the DTCs cannot be performed by removing the battery cable or ECU-IG fuse.

2. DTC CHECK (USING HAND-HELD TESTER)**(a) Checking DTCs.**

- (1) Connect the hand-held tester to the DLC3.
- (2) Turn the ignition switch to the ON position.
- (3) Read the DTC by following the prompts on the tester screen.

HINT:

Refer to the hand-held tester operator's manual for further details.

(b) Clearing the DTCs.

- (1) Connect the hand-held tester to the DLC3.
- (2) Turn the ignition switch to the ON position.
- (3) Operate the hand-held tester to erase the codes.

HINT:

Refer to the hand-held tester operator's manual for further details.